Air Locker

Model # RN45AB2



No.	Description	Qty.	No.	Description	Qty.	No.	Description	Qty.	No.	Description	Qty.
1	Screw	1	31	O-Ring	1	50	Rubber Pad(B)	1	81	Pin	1
2	Washer	1	32	O-Ring	1	52	Protection Bracket(B)	1	82	Pin	1
3	O-ring	1	33	O-Ring	1	53	Body	1	64	Handle Grip	1
4	Exhaust Cover	1	34	Trigger valve guide	1	119	**Piston Driver Guide**	1	65	Rubber Pad(A)	1
5	Washer	1	35	O-Ring	2		**Assembly**	1	66	Screw	1
6	Screw	4	36	Spring	1	7	Washer	1	68	Protection Bracket(A)	1
7	Washer	5	37	Trigger valve stem	1	56	O-Ring	5	121	**Magazine Assembly**	1
8	Cylinder Cap	1	38	Seal,Air	1	57	Screw	2	83	Rubber Pad(B)	1
9	Gasket	1	51	Pin	1	58	Outlet Site	1	84	Protection Bracket(B)	1
10	Washer	1	54	Pin	3	63	Ring	1	85	Magazine	1
11	Piston Stopper	1	39	Spring	1	67	Screw	2	86	Pin	1
12	Spring	1	117	**Trigger Assembly**	1	69	Tail cover	1	87	Sliding Block	1
13	O-Ring	1	107	Pin	1	70	Stopper	1	88	Washer	1
14	O-Ring	3	108	Spring	1	71	Spring	3	89	Stopper	1
15	Head Valve Piston	1	109	Contact lever	1	72	O-Ring	1	93	Tail Cover	1
16	Lining Ring	1	110	Trigger	1	73	Piston Head	1	94	Pin	1
17	Cylinder Ring	1	111	Pin	1	74	Spring	1	95	O-Ring	1
113	**Driver Blade Set**	1	112	Trigger rotating wrench	1	75	Pin	1	96	Stopper (A)	1
18	Screw	1	118	**Safety Pushing Lever**	1	76	O-ring	1	97	Tray	1
19	Washer	1		**Assembly**		77	Pusher	1	98	Screw	1
20	O-ring	1	40	Ring	1	116	Washer	1	99	Spring	1
21	Driver Piston	1	41	Catch Guide Plate	1	57	Screw	1	100	Screw	3
22	Driver Blade	1	42	Spring	1	120	**Magazine Door**	1	101	Stopper(B)	1
23	O-Ring	1	43	Release Catch	1		**Assembly**	1	102	Rubber Pad(A)	1
24	Spacer	1	44	Catch Guide Plate	1	59	Stopper A	1	103	Protection Bracket(A)	1
25	O-ring	1	45	Screw	1	60	Spring	2	104	Spring	1
26	Cylinder	1	46	Release Catch B	1	61	Stopper B	1	105	Pin	1
27	Bumper	1	47	Spring	1	62	Pin	1	106	Click Lever	1
115	**Trigger Valve Set**	1	48	Screw	1	63	Ring	1	90	Gasket	1
28	O-Ring	1	49	Release Catch A	1	78	Gate Lock	1	91	Tail cover	1
29	O-Ring	1	55	Pin	1	79	Spring	1	92	Screw	3
30	Trigger valve head	1	116	Washer	1	80	Door	1			